


How to Weigh a V-Drive Ski/Wakeboard Boat

W711 Fatsac can be used if the nose of the boat is open underneath the cushion to pass it



If you weigh your V-Drive boat like this diagram shows, people will not have to learn to wakesurf behind it, they will immediately be able to do it the first time. People that already know how to wakesurf will be able to do bigger tricks without losing the wake.

NOTE: *When weighing your boat like this, make sure to give the boat a little throttle to bring the bow of the boat up enough when passing through wakes so they don't wash over the front of the boat.*

This diagram shows the way to weigh a V-Drive ski/wakeboard boat for wakesurfing. Fill all factory ballast if there are any in the V-Drive in addition to the sacs shown on the diagram to first get the whole boat down deep in the water. Put the Ultimate Wake Surf Sac (W718) on top of the rear seat & side seat that you are wakeboarding on, to get the rear corner of the boat you are surfing on extra deep in the water. This will displace the most water & create the biggest possible wake. The diagram shows it on the passenger side for wakesurfing on the passenger side. Put the Ultimate wakesurf Sac (W718) in the same place on the driver side for wakesurfing on the driver side. The Ultimate Wakesurf Sac (W718) is symmetrical so the fittings are on top and on the bottom so you can put it on the rear seat and side seat you are wakesurfing on & have the fittings on top to fill & empty from.

NOTE: *It is important to hold the Ultimate Wakesurf Sac (W718) when you are filling and emptying it but when it is full it is firm so it cannot roll off the seats because it is shaped like a 'L'*

NOTE: *One of the great things about fat sacs is that it doesn't matter if they are the same size and shape as the compartment or space they are going in because they will conform. If you want maximum weight out of a space or compartment you need to go with sacs at least as big, if not bigger than the space or compartment so when you fill them & they conform they will fill up the whole area and give you maximum weight out of it.*